



- NOTES
- 1.) IF PILOT PTT SWITCH IS CONNECTED TO THE AIRCRAFT HAND MIC JACK, IT MUST BE DISCONNECTED AND CONNECTED TO THE WHITE/RED WIRE AS SHOWN.
 - 2.) AIRCRAFT CHASSIS GROUND.

Figure 4

SPA-4S INSTALLATION DRAWING